



WARRANTY INFORMATION

We sincerely thank you for your purchase and wish you years of pleasure using it!

Tele Vue Warranty Summary

Eyepieces, Barlows, Powermates, & Paracorr have a “Lifetime Limited” warranty, telescopes & accessories are warranted for 5 years. Electronic parts are warranted for 1 year. Warranty is against defects in material or workmanship. No other warranty is expressed or implied. No returns without prior authorization. Please keep your receipts in case you need warranty service.

Lifetime Limited Warranty details online: <http://bit.ly/TVOPTLIFE>

5-Year/1-Year Warranty details online: <http://bit.ly/TVOPTLIMITED>

Subscribe to our Blog for the latest Tele Vue news: <https://bit.ly/TeleVueBlog>

Keep For Your Records

Dealer: _____ City/State/Country: _____

Date (day/month/year): ____ / ____ / ____ Item Code / Description _____

32 Elkay Dr., Chester, New York 10918 (845) 469-4551. televue.com



@televueoptics

Adapter DEA-0001 & DNA-6000 for DIOPTRX™

DEA-0001 to 24mm Panoptic (and 19mm Panoptic, 20mm Nagler Type-5) and DNA-6000 to Nagler Type-6

These adapters convert eyepieces with small eyeguards to larger eyeguards, so DIOPTRX can be installed. Note that these eyepieces have shorter eye relief than others recommended for DIOPTRX, so to minimize any vignetting, it's best to use these for deep-sky applications where your eye pupil is large.

Installation

1. Remove small rubber eyeguard from eyepiece
2. Place adapter over eyepiece, making sure adapter lip is toward eye
3. Tighten the 3 set screws using the supplied Allen wrench
4. Slip on new supplied larger rubber eyeguard for normal use, or attach DIOPTRX as desired.



Eyeguard removed

Adapter over eyepiece

Eyeguard over adapter

DIOPTRX over eyepiece



Notes on DEA-0001 When used for bino-viewers, you may encounter "nose relief" limitations because DIOPTRX reduces the normal eyepiece eye relief.

Notes on DNA-6000 When used for bino-viewers, remove DIOPTRX, because limited "nose-relief" and eye-relief will prevent seeing the full 82° field. The new larger eyeguards are still fine for use with binocular viewers.



For information call 9 a.m. — 5 p.m. ET Monday through Friday: 845 469 4551 or visit www.TeleVue.com.
Copyright © 2006 Tele Vue Optics, Inc., 32 Elkay Dr., Chester, NY 10918. All rights reserved.

Rev: 10/9/2008 DEA-0001 & DNA-6000

Adapter DEA-0001 & DNA-6000 for DIOPTRX™

DEA-0001 to 24mm Panoptic (and 19mm Panoptic, 20mm Nagler Type-5) and DNA-6000 to Nagler Type-6

These adapters convert eyepieces with small eyeguards to larger eyeguards, so DIOPTRX can be installed. Note that these eyepieces have shorter eye relief than others recommended for DIOPTRX, so to minimize any vignetting, it's best to use these for deep-sky applications where your eye pupil is large.

Installation

5. Remove small rubber eyeguard from eyepiece
6. Place adapter over eyepiece, making sure adapter lip is toward eye
7. Tighten the 3 set screws using the supplied Allen wrench
8. Slip on new supplied larger rubber eyeguard for normal use, or attach DIOPTRX as desired.



Eyeguard removed

Adapter over eyepiece

Eyeguard over adapter

DIOPTRX over eyepiece



Notes on DEA-0001 When used for bino-viewers, you may encounter "nose relief" limitations because DIOPTRX reduces the normal eyepiece eye relief.

Notes on DNA-6000 When used for bino-viewers, remove DIOPTRX, because limited "nose-relief" and eye-relief will prevent seeing the full 82° field. The new larger eyeguards are still fine for use with binocular viewers.



For information call 9 a.m. — 5 p.m. ET Monday through Friday: 845 469 4551 or visit www.TeleVue.com.
Copyright © 2006 Tele Vue Optics, Inc., 32 Elkay Dr., Chester, NY 10918. All rights reserved.

Rev: 10/9/2008 DEA-0001 & DNA-6000